

BEAD IT! M LOW VOLATILE BLACK RTV SILICONE GASKET MAKER



800-890-7935

Directions:

IMPORTANT: NOT TO BE USED FOR HEAD GASKETS OR CARBURETOR BASE.

- 1. Remove old gasket.
- Use a non-flammable cleaner such as Well Worth's BRAKE AWAY Brake Cleaner to remove all oil and grease. Make certain surface is clean and dry.
- 3. Hold nozzle at 45° angle and with even pressure, draw a bead (1/16" to 1/8" wide) in any direction.
- 4. Using a clean dry cloth or knife, wipe away any excess RTV Silicone.
- 5. Wait 15 minutes for bead to skin before re-assembling parts. Make sure parts are properly aligned the first time. Don't over tighten bolts.

IMPORTANT: TO SELF CLOSE CAN, ALWAYS ALLOW ½" OF BEAD IT!™ TO EXTEND PAST STEM OPENING. ON NEXT USE, PULL UPWARD TO REMOVE CURED PLUG FROM STEM.

Product Number and Packaging: #6006 - 12/CS

CONTAINS: Triacetoxyethylsilane (17689-77-9), Methylsilanetriyl Triacetate (4253-34-3), 1,1 Difluoroethane (75-37-6).

Read Well Worth SDS before use. Chemtrec (USA) 800-424-9300

KEEP OUT OF REACH OF CHILDREN

www.wellworthproducts.com





WARNING: CONTACT WITH UNCURED SEALANT CAUSES IRRITATION. CONTENTS UNDER PRESSURE. OUTER CONTAINER IS PRESSURIZED WITH A FLAMMABLE HYDRO FLOURO CARBON PROPELLANT. DO NOT REMOVE RUBBER PLUG.

CONTAINS GAS UNDER PRESSURE; MAY EXPLODE IF HEATED. CAUSES SERIOUS EYE AND SKIN IRRITATION.

PREVENTION: Wear protective gloves. Wear eye or face protection. Wash hands thoroughly after handling

RESPONSE:

IF ON SKIN: Wash with plenty of soap and water. Take off contaminated clothing. Wash contaminated clothing before reuse. If skin irritation occurs: Get medical attention.

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical attention.

STORAGE: Protect from sunlight. Store in well-ventilated place

DISPOSAL: Not applicable.